

OWASP #30

Authentication topic

Teemu Simonen
11.10.2016



- Something the user knows
- Something the user has
- Something the user is

- Combined when need authentication
 - Web, Mobile, Users, Devices, Servers



■ Something the user knows

- Username & Password
- Smart Card PIN



■ Something the user has

- OTP list, PKI, Mobile devices, Token devices, Smart Cards
- Biometrics



■ Something the user is

- Biometrics



- FAR (false accept rate)
- FRR (false reject rate)
- Registration
- 1 to 1 verification
- 1 to N identification



Use case: Biometric authentication to web applications **FUJITSU**

■ Registration

- Capture biometric data
- Transform image into pattern data
- Save data as biometric authentication template

■ Authentication



- Compare captured data against the saved template



Use case: Biometric authentication to web applications **FUJITSU**

■ Demo: Using palm vein authentication (mPollux PalmSign with PalmSecure)

- Web application
- Log-in to desktop



Use case: Biometric authentication to web applications **FUJITSU**

Authentication page (localhost:8000)

Please select authentication method

PalmSecure (Hand icon) **Classic** (Password icon)

Please wait...

PalmSecure Capture

Hand closer

PalmSecure Authentication Server

Logout

Administrative functions

Manage user accounts **User editor**

Developer functions

Show all variables...
Show ssl help page...

PalmSecure Application

Database About ...

Local user database

| Domain | Username |
|--------|----------|
| | |

Identify user ... Delete selected user ...

mPollux Server

Identify against mPollux Server

User registration

Username Password Domain

Enroll new user ...

Close

■ PalmSecure®

- Palm Vein Authentication based on vascular pattern recognition
- Capture near-infrared image of unique palm vein pattern
- FAR (false accept rate) 0.00001%
- FRR (false reject rate) 1.0% F Pro sensor: 0.01% (one retry)
- The maximum number for 1 to N identification authentication is 10,000 palms (5,000 persons if both hands enrolled)
- <http://www.fujitsu.com/us/solutions/business-technology/security/palmsecure/palmsecurresso/>

■ PalmSecure®

- Palm Vein Authentication based on vascular pattern recognition
- Capture near-infrared image of unique palm vein pattern
- FAR (false accept rate) 0.00001%
- FRR (false reject rate) 1.0% F Pro sensor: 0.01% (one retry)

■ Apple fingerprint Touch ID

- FAR (false accept rate) 0.002% (1 in 50,000)
- FRR (false reject rate) unknown
- <https://support.apple.com/en-us/HT204587>

■ 4 digit PIN code guessing

- FAR (false accept rate) 0.01% (1 in 10,000)

■ PalmSecure® Sensors:

■ Temperature

■ Sunlight

V2

0°C-60°C


Max. 3,000 lux

F Pro (new model)

-40°C-85°C

Max. 80,000 lux

Ability to correct
hand movements



PalmSecure Sensor V2
(35mm×35mm×27mm)

PalmSecure-F Pro
(29mm×29mm×13mm)

<http://www.fujitsu.com/global/about/resources/news/press-releases/2016/0912-01.html>

Use case: PKI authentication in web application context can be easy

■ Demo: Smart card personalization self-service

| CA related settings | |
|-----------------------|--|
| Certification profile | |
| Key type | |

| User data editor | |
|---------------------|---------------------|
| Given name | Test |
| Surname | User |
| Common name | Test User |
| email | test.user@email.com |
| UPN | upn@testdomain.com |
| Organization | Fujitsu Finland Oy |
| Organizational unit | Varmennepalvelut |

| Card related settings | |
|-----------------------|------------|
| Card serial number | |
| Initialization script | Dynamic-en |
| PIN1 | |
| PIN2 | |
| PUK1 | |
| PUK2 | |
| SO-PIN | |
| SO-PUK | |
| Old SO-PIN | |

Continue and personalize card...

Cancel and return to main menu...

Close

| CA related settings | |
|-----------------------|----------------------------------|
| Certification profile | Fujitsu Finland Development CA ▼ |
| Request type | Signature ▼ |
| Key type | ECC, secp256r1 ▼ |

| User data editor | |
|---------------------|---------------------|
| Given name | Test |
| Surname | User |
| Common name | Test User |
| email | test.user@email.com |
| UPN | upn@testdomain.com |
| Organization | Fujitsu Finland Oy |
| Organizational unit | Varmennepalvelut |

Continue building PKCS#12 package...

Cancel and return to main menu...

Use case: PKI authentication in web application context can be easy



■ Demo: Smart card personalization self-service

| Card personalization test page | |
|--|--|
| 1. Setup environment | Done |
| 2. Select smart card reader | SCM Microsystems Inc. SCR33x USB Smart Card Reader 0 |
| 3. Insert card | JCOP with MyEID Applet (T=1) |
| 4. Verify SO-PIN | PIN verification ok |
| 5. Initialize card | Please wait... |
| 6. Generate keypair | |
| 7. Request certificate from CA and store to card | |
| 8. Insert ROOT certificate to card | |
| 9. Insert intermediate certificate to card | |
| 10. End of task | |

| Card personalization test page | |
|--|--|
| 1. Setup environment | Done |
| 2. Select smart card reader | SCM Microsystems Inc. SCR33x USB Smart Card Reader 0 |
| 3. Insert card | JCOP with MyEID Applet (T=1) |
| 4. Verify SO-PIN | PIN verification ok |
| 5. Initialize card | Card initialized. SN = 169980000000000010 |
| 6. Generate keypair | Received public key from client |
| 7. Request certificate from CA and store to card | Certificate stored to card |
| 8. Insert ROOT certificate to card | Certificate stored to card |
| 9. Insert intermediate certificate to card | Certificate stored to card |
| 10. End of task | Done, return to main ... |

Use case: PKI authentication in web application context can be easy

■ Demo: Smart card personalization self-service



Document information & history


Title Biometric authentication for web applications

Customer/Project Fujitsu

Owner Teemu Simonen

Classification Unclassified

| Date / Version | Author | Status | Reviewed by | Changes |
|----------------|---------------|--------|-------------|--|
| 10.10.2016 | Teemu Simonen | | | First version |
| 12.10.2016 | Teemu Simonen | | | Added comparison FAR and FRR and certificate image |
| | | | | |
| | | | | |



shaping tomorrow with you